



SAFELINK

THE ALARM WI-FI GATEWAY

Get notified anytime, anywhere



WI-FI



DATA
SECURITY



EASY DIY
INSTALL



AUSTRALIAN
OWNED




emerald

What is SafeLink

Protect your loved ones and stay connected by receiving alerts when your smoke alarms are triggered - even when you're not at home.

The SafeLink is a gateway between the Emerald app and your radio frequency (RF) Emerald alarms, allowing you to view your alarms' real-time status via your mobile phone.

The Emerald app instantly notifies you when your smoke alarms are triggered, allowing you to locate an activated alarm and routinely test your alarms to protect your loved ones and home from danger.



How SafeLink works

STAY INFORMED. STAY PROTECTED.

The SafeLink and the Emerald app are easy to set up and use. Designed with the user's needs in mind, the Emerald app provides the most simple interface available.

Set up your SafeLink in a central location of your home and follow the in-app pairing instructions to establish the link between your SafeLink and Emerald RF alarms.



1. Download the Emerald app



2. Plug in your SafeLink



3. Connect SafeLink to your phone



4. Connect SafeLink to smoke alarm/s



Safelink features

- Test and locate your RF enabled alarms via your phone
- Get notified when alarms are triggered on your phone – anytime, anywhere
- Link quick dial contacts
- Test alarms via your phone
- Alarm event history, triggers and network testing results
- Humidity and temperature sensors



Get notified regardless of where you are in the world thanks to SafeLink's Wi-Fi connectivity.



SafeLink accessibility*

THE VULNERABLE

Add family members and carers to the network so that they can be notified in the event of the smoke alarms being triggered.

HEARING IMPAIRED

Assists people living with hearing impairments by prompting their mobile to continually vibrate.

VISION IMPAIRED

Assists people living with vision impairments with voice alerts on their mobile.

*Subject to device compatibility

MODEL NUMBER:	EEMS-SAFEL-RF-WIFI
DIMENSIONS:	80 x 80 x 35mm
WEIGHT:	133g
WARRANTY:	2 years
POWER SUPPLY MODE:	Type-C
VOLTAGE:	5V
INPUT CURRENT:	1A
WIRELESS MODE:	RF, Wi-Fi
OPERATING FREQUENCY:	433Mhz (RF), 2.4Gz (Wi-Fi)
WI-FI RANGE:	Indoor 35m / Outdoor 90m (subject to home layout)
RF RANGE:	Indoor 35m / Outdoor 100m (subject to home layout)
INSTALLATION:	Wall mounting / Desktop
NORMAL OPERATING & STORAGE TEMPERATURE:	0° to 55°
NORMAL OPERATING & STORAGE HUMIDITY:	≤ 95% RH Non-condensate
PACK INCLUDES:	Type C power cable, plug, screws and mounting plate

Compatible Emerald Alarms

Emerald's SafeLink is designed to connect via Wi-Fi to our quality range of RF enabled alarms.



**10 YEAR BATTERY POWERED
RADIO FREQUENCY (RF)**
EP-RANG-RF-10



**240V HARD-WIRED
1 YEAR BATTERY BACK UP**
EP-VC-240-1



**240V HARD-WIRED
10 YEAR BATTERY BACK UP**
EP-VC-240-10



**HYBRID
10 YEAR BATTERY POWERED OR
240V HARD-WIRED**
EP-HYB-240-10



**HYBRID
10 YEAR BATTERY POWERED OR
240V HARD-WIRED (RF)**
EP-HYB-240-RF-10



**HYBRID
10 YEAR BATTERY POWERED OR
240V HARD-WIRED**
EP-HYB-240-10B



Find out more
emeraldhome.com.au



2024.04